



Microfiltrex – a Division of the Porvair Filtration Group Ltd.
Fareham Industrial Park, Fareham, Hampshire PO16 8XG UK

T : +44 (0)1329 285616
Email : info@porvairfiltration.com

F : +44 (0)1329 822442
www.porvairfiltration.com

PRESS RELEASE *June 2004*

Filtration Solutions for the Beverage Industry



Microfiltrex Trapfil is a new microfilter specifically developed for the reliable removal and retention of diatomite and Polyvinylpolypyrrolidone (PVPP) particles.

Trapfil filter cartridges are manufactured from a multi-layer combination media, precision pleated and thermally seam-bonded to maximise the available filtration area and to ensure an efficient flow throughout the cartridge. Constructed from 100% FDA approved materials, the Trapfil cartridge can be repeatedly in situ-steam sterilised up to 130°C and repeatedly hot water sanitised up to 90°C. Regeneration of the filter by backflushing gives greater life and reduces costs. The Trapfil is available in absolute ratings 5, 10 and 15 micron. The Trapfil enables breweries to produce beer with excellent clarity and low turbidity.

Microfiltrex is working in partnership with brewers to continually develop filtration products for applications in the brewery. Products are designed to compliment other brewery processes to enhance product quality at each stage of production, without adversely affecting desirable characteristics.

Microfiltrex is a division of the Porvair Filtration Group, a specialist porous media and filtration company with expertise in a wide range of media and many years experience in filtration. The Porvair Filtration Group designs and manufactures high performance filters for the most demanding environments in industries including aerospace and defence, chemical process, power generation, oil and gas, pharmaceutical and healthcare, air and water.

For further details please contact Christine Chapple on 01329 228161 or email info@porvairfiltration.com