



Microfiltrex – a Division of the Porvair Filtration Group Ltd.  
Fareham Industrial Park, Fareham, Hampshire PO16 8XG UK

T : +44 (0)1329 285616  
Email : [info@porvairfiltration.com](mailto:info@porvairfiltration.com)

F : +44 (0)1329 822442  
[www.porvairfiltration.com](http://www.porvairfiltration.com)

## PRESS RELEASE

*July 2005*

### Reliable filter for the brewing industry



Since its launch last summer, the Microfiltrex Trapfil polymeric filter cartridge has been the filter of choice of 4 major brewery chains across the UK for continued use in their production lines. Working closely with brewers to continually develop filtration products for applications in the brewery, the Trapfil was specifically developed by Microfiltrex for the reliable removal and retention of diatomite and polyvinylpolypyrrolidone (PVPP) particles. With an effective filtration area of 0.35m<sup>2</sup> per 10" cartridge, the Trapfil filter is reliable at reducing contamination levels and enhancing product quality at each stage of production, without adversely affecting desirable characteristics.

Trapfil filter cartridges are manufactured from a multi-layer combination media, precision pleated and thermally seam-bonded to maximise the available filtration area and to ensure an efficient flow throughout the cartridge. Constructed from 100% FDA approved materials, the Trapfil cartridge can be repeatedly in situ-steam sterilised up to 130°C and repeatedly hot water sanitised up to 90°C. Regeneration of the filter by backflushing gives greater life and reduces costs. The Trapfil is available in absolute ratings 5, 10 and 15 micron. The Trapfil enables breweries to produce beer with excellent clarity and low turbidity.

Microfiltrex is a division of the Porvair Filtration Group, a specialist porous media and filtration company with expertise in a wide range of media and many years experience in filtration. The Porvair Filtration Group designs and manufactures high performance filters for the most demanding environments in industries including aerospace and defence, chemical process, power generation, oil and gas, pharmaceutical and healthcare, air and water.

*For further details please contact Bob Wilkinson on 01329 228163 or email [info@porvairfiltration.com](mailto:info@porvairfiltration.com)*